


Re: Using UIO8 Test Utility

To all of our customers and partners;


Follow the instructions below to assign a unique IP address to each UIO8 device through UIO8 Test Utility included on your installation CD that came with the UIO8 device.

1. Run UIO8 Test utility from the installation CD and check the UIO8 information


- Run UIO8 test utility.
- Click "Refresh" to show all available UIO8 units within network.




2. Select desired UIO8 device from the list and change the IP address.



- Select the UIO8 device in the list.
- In the "Change IP Setting" area, enter the new unique IP Address (and port number, if applicable) for the device
- Click the **Save** button to apply changes.
- Wait for the "Changing IP successful!" pop-up message.
- Click **OK** to close the message window.



- Click the **Refresh** button to show the new IP address and port number in the list.



Please contact technical support at support@i3international.com or by phone: 1.877.877.7241 if you have any questions or issues.

i3 International Inc.
 Technical Support and Services
 1.877.877.7241
support@i3international.com