

Each i³ Rackmount DVR unit can accept an extra **four** (Intel DH55HC motherboard) or **eight** (with additional hardware) hard drives. The extra hard drive installation is easy and does not require opening the unit cover. Please use i³ approved hard drives **only**. All additional hard drives used with i³ units must be Seagate SATA, DVR Surveillance edition hard drives. Using regular hard drives in the DVR application will cause the system to overheat, system crash may also occur as a result.

REMEMBER:

- Handle hard drives with care
- Do not subject the drive(s) to any physical shock
- Always ground yourself before handling hard drives.

List of i³-approved SATA hard drives:

- I-ST380815AS (Seagate 80GB Surveillance)
- I-ST3320620AS (Seagate 320GB Surveillance)
- I-ST3320620SV (Seagate 320GB Surveillance)
- I-ST3500630SV (Seagate 500GB Surveillance)
- I-ST3750330SV (Seagate 750GB Surveillance)
- I-ST3750640SV (Seagate 750GB Surveillance
- I-ST31000340SV (Seagate 1TB Surveillance)
- I-ST31000525SV (Seagate 1TB Surveillance)

Step 3.

Parts needed:

i³ approved SATA Seagate hard drive(s) (DVR Surveillance edition) Philips screwdriver

Step 1.





Shut down the DVR and unplug the power. Open the unit door and locate the SATA hard drive enclosure.

All hard drive bays should be locked. Use the hard drive bay keys shipped with the unit to unlock an empty bay.

Place your thumb on the lower portion of the empty bay and push it downwards, this will make the bay come forward and the upper portion of the bay to elevate.



Firmly hold the top portion of the hard drive bay and pull the bay forward.

The empty hard drive bay will slide out of the SATA enclosure. Remove the bay from the enclosure.

i³ INTERNATIONAL TECHNICAL BULLETIN Technical Bulletin # 110525-HW-02



Adding a Hard Drive to i³ Rackmount units

Step 4.



Ground yourself and slide the new hard drive inside the provided hard drive bay as shown on the picture. The hard drive circuitry should remain exposed (see image).

Step 5.



Place the bay with the inserted hard drive flat on a clean, leveled and stable surface.

Locate four (4) small bay screws (shipped separately inside the accessory box).

With the Philips screwdriver screw the hard drive to the hard drive bay as shown on the picture. Step 6.



Slide the hard drive bay with the new hard drive inside the hard drive bay slot. Push the top portion of the bay into place to lock the bay into the SATA enclosure box.

Use the keys provided (shipped separately inside the accessory box) and lock all bays that contain hard drives.

Repeat all above steps for all additional drives.

i³ INTERNATIONAL TECHNICAL BULLETIN Technical Bulletin # 110525-HW-02

Connect the power to the unit and power up the DVR.

Now that the additional drive has been added to the system, it needs to be partitioned in accordance with i³ standards.

Partitioning a Hard Drive in XP Embedded 3.0 or higher

During the DVR booting stage, enter the BIOS setup by pressing F2 on your keyboard.

- 1. In the BIOS setup, go to Advance -> Drive Configuration. Set ATA/IDE Mode to NATIVE, then press F10 and Y key to save settings and exit BIOS.
- 2. Wait for the Windows OS and the SRX-Pro Server to load. Then log into the SRX-Pro Server as a master user and press Alt + Shift + Ctrl + F4 on your keyboard to exit SRX-Pro Server and access the Desktop.
- 3. Click the START button on the Desktop

Adding a Hard Drive to i³ Rackmount units



- 4. Right-click on **My Computer** and select **Manage** from the context menu. Computer Management window will be displayed.
- 5. In the left pane, select Disk Management. In the right pane, the system physical drives are displayed. The newly installed hard drive will be marked "Unallocated". Please ensure that the unallocated drive is identified as **BASIC**, not *Dynamic**.

| 📙 Computer Management | | | | | | | | | _ 8 × |
|--|---|---|---|---------|---|--|---|--|-------|
| 📃 File Action View Window H | elp | | | | | | | | _ B × |
| ← → 🗈 🔳 😫 🖸 🗙 🖆 | ' 🚅 🔯 | | | | | | | | |
| Computer Management (Local) System Tools System Tools Shared Folders Discal Users and Groups Device Manager Storage Disk Defragmenter Disk Management Services and Applications | Volume Layout (C:) Partition (D:) Partition (E:) Partition (F:) Partition | Basic FAT32 Basic NTFS | Status Healthy (System) Healthy Healthy Healthy | | Free Space 6.17 GB 22.83 GB 446.33 GB 448.58 GB | % Free 63 % 93 % 99 % 99 % | Fault Tolerance No No No No | Overhead 0% 0% 0% 0% | |
| | Basic 931.51 GB Online | (C:) 9.77 GB NTF5 Healthy (System) | (D:) 24.42 G Healthy | B FAT32 | 4 | (E:) 48.66 GB N ealthy | TFS | (F:) 448.66 GB NTFS Healthy | |
| | Cisk 1 Basic 931.50 GB Online | 931.50 G8 Unallocated | | | | | | | |
| | Cisk 2 Basic 931.50 GB Online | 931.50 GB Unallocated | | | | | | | |
| | DVD | | | | | | | | |
| <u>د</u> | Primary partition | Extended partition | n 📘 Logical drive | | | | | | |

* If the drive is identified as Dynamic, right-click and select Convert to Basic Disk... from the context menu.

- 6. In the right pane, right-click on CD-ROM 0 drive and select Change Drive Letter and Paths... in the context menu.
- 7. In the new window, click Change...
- 8. In the Change Drive Letter or Path window, select the drive letter **M** and click **OK**. Click **Yes** in the confirmation window.
- **9.** Right-click on the black bar of the unallocated drive (usually Disk 1) and select **New Partition** from the context menu.
- **10.** In the new window, click **Next**. Select Extended Partition, click **Next** twice. Click **Finish**. The black bar will become green to indicate that the drive was converted to an extended partition.
- 11. Right-click on the green bar of the new drive and select **New Logical Drive...** from the context menu.
- Enter the value of Partition size in MB.
 To calculate the size of each partition, divide new hard drive's total capacity by two or four, depending on the number of partitions desired.
- **13.** Click **Next**. Make sure that the selected drive letter is the first available letter in a sequence. Click **Next** again.
- 14. In the New Partition Wizard window, erase the Volume label and check off the Perform a quick format checkbox. Click Next. Click Finish.

i³ INTERNATIONAL TECHNICAL BULLETIN Technical Bulletin # 110525-HW-02





 Repeat steps 11-14 until new drive has been partitioned into 2 or 4 equal partitions, depending on user preference. The drive letters of all partitions should form an uninterrupted sequence (i.e. G,H,I,J). See image below.

| 📙 Computer Management | | | | | | | | | _ 8 > |
|--------------------------------------|----------------------------------|--------------------------|--------------------|------------------------|------------|----------------------------|-----------------|---------------------------|-------|
| 📕 File Action View Window H | elp | | | | | | | | _ 8 × |
| ⇔ ⇒ 🗈 🖬 😫 🐼 🗙 🖆 | ' 🚅 🔯 | | | | | | | | |
| Computer Management (Local) | Volume Layout | Type File System | | Capacity | Free Space | | Fault Tolerance | Overhead | |
| ⊡-∰s System Tools ⊡- Event Viewer | C:) Partition | Basic NTFS | Healthy (System) | | 6.17 GB | 63 % | No | 0% | |
| Event viewer Folders | (D:) Partition | Basic FAT32 | Healthy | 24.41 GB | 22.83 GB | 93 % | No | 0% | |
| Local Users and Groups | (E:) Partition | Basic NTFS | Healthy | | 446.33 GB | 99 % | No | 0% | |
| Performance Logs and Alerts | (F:) Partition | Basic NTFS | Healthy | 448.66 GB | | 99 % | No | 0% | |
| 🛄 Device Manager | (G:) Partition (H:) Partition | Basic NTFS Basic NTFS | Healthy Healthy | 465.75 GB 465.75 GB | | 99 % 99 % | No No | 0% 0% | |
| 🖻 🚵 Storage | (I:) Partition | Basic NTES | Healthy | 465.75 GB | | 99 % 99 % | No | 0% | |
| 🕀 😭 Removable Storage | (J:) Partition | Basic NTFS | Healthy | 465.75 GB | | 99 % | No | 0% | |
| - 🙀 Disk Defragmenter | | Dasic NIFS | nealury | 400.70 GD | 403.07 GD | 99 70 | NO | 0.76 | |
| Disk Management | | | | | | | | | |
| Services and Applications | | | | | | | | | |
| | | 1 | | | | | | | |
| | 🗇 Disk 0 | | | | | | | | |
| | Basic 931.51 GB | (C:) 9.77 GB NTFS | (D:) | 0.54700 | | (E:) 48.66 GB N | TEC | (F:) | |
| | Online | Healthy (System) | Healthv | B FAT32 | | 48.66 GB N ealthy | IIFS | 448.66 GB NTFS Healthy | |
| | | | 1 | | | , | | 1 | |
| | 🗇Disk 1 | | | | | | | | |
| | Basic 931.50 GB | (G:) 465.75 GB NTFS | | | | (H:) 465.75 GB NTFS | | | |
| | Online | Healthy | | | | Healthy | | | |
| | | 1 | | | | , | | | |
| | Disk 2 | | | | | | | | |
| | Basic 931.50 GB | (I:) 465.75 GB NTFS | | | | (J:) 55.75 GB N | TEC | | |
| | Online | Healthy | | | | ealthy | 11-5 | | |
| | | · · · | | | | | | | |
| | DVD | | | | | | | | |
| | Online | | | | | | | | |
| | | | | | | | | | |

This completes the new hard drive configuration. Restart SRX-Pro Server, go to Setup -> Storage Setup and allocate all new partitions for video recording.

Please contact technical support at <u>support@i3dvr.com</u> or by phone: 1.877.877.7241 if you have any other questions or issues.

Thank you very much for your attention and cooperation.

Best regards,

i³ International Inc. Technical Support and Services 1.877.877.7241 support@i3international.com

> i³ INTERNATIONAL TECHNICAL BULLETIN Technical Bulletin # 110525-HW-02