

Re: Removing BNC Board from a Rackmount DVR

To all of our customers and partners;


Occasionally your i³ Rackmount Server will have to be removed from site for service, maintenance or update. The new Rackmount chassis design (i8 and i9 series) allows you to simplify the process of removing and re-installing the Server on site. You have an option of removing the BNC board, still connected to the analog inputs, from Server.



These instructions are meant for i³-certified dealers **only**. Any damage to the unit caused by the technician without a current i³ certification is not covered under i³ warranty.

Please follow the instruction below to remove the BNC board:

1. Ground yourself. Any damage to the unit caused by static electricity is not covered under i³ warranty.
2. Locate the BNC panel on the i8 or i9-series Rackmount unit



3. Use a flat-head screwdriver to unscrew the BNC panel.



4. Grip the left side of the panel with your left hand and push on the right side of the panel with your right hand to slide the panel out.



5. Gently pull on the BNC panel to lift it out of the chassis. Disconnect the rainbow cable and separate the BNC board from the chassis.



6. Leave the BNC panel on site, still attached to the analog inputs. Service the Server as needed.

Please contact technical support at support@i3international.com or by phone: 1.877.877.7241 if you have any questions or issues.

i3 International Inc.
Technical Support and Services
1.877.877.7241
support@i3international.com